

DUPLEX RESIN

Photopolymer resin for DLP/LCD/SLA 3D printers

Material Data Sheet

v.1.0



Illustration only.
Actual product may differ.

Volume: 1000 ml

Curing wavelength: 405nm

General instructions:

- Shake bottle well before use.
- Do not refill used resin into bottle.
- When printing with used resin, filter, stir and shake well.
- Keep container tightly closed. Store locked up in a dark, dry place.
- Use at room temperature.

Material Safety

PRECAUTIONS

Use only outdoors or in a well-ventilated area. Wear protective gloves/protective clothing/eye protection/face protection. Absorb spillage with suitable absorbent material. Transfer to a container for disposal.

STORAGE

Store in tightly closed original container in a dry and cool place. Protect from freezing and direct sunlight. Keep away from heat, sparks and open flame. Keep away from human and animal food and drinks. Keep between 5 - 25 °C.

DISPOSAL

Dispose of contents/container in accordance with national regulations. Avoid discharge to the aquatic environment. Do not discharge into drains, water courses or onto the ground.



WARNING: Causes skin irritation. Avoid contact with skin.

WHEN CONTACTS SKIN: Wash contaminated skin thoroughly with plenty of soap and water.



WARNING: Causes serious eye irritation. Avoid contact with eyes.

WHEN CONTACTS EYE: Rinse cautiously with water for several minutes. Remove contact lenses, if applicable. Continue rinsing. Seek medical advice/attention.



WARNING: May cause respiratory irritation. Avoid breathing vapor/spray.

WHEN INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing.

MSDS available upon request.



www.duplex3d.com



Grante Corp.
2509 Esztergom Dorogi u.5-7.
+36 33 512 468
grante@grante.hu